

Transmitter Quick Specs

Pushbutton:	SAGA1-L10 (8 Double-step Pushbuttons + Rotary Start Key + EMS Pushbutton) SAGA1-L10-1 (8 Single-step Pushbuttons + Rotary Start Key + EMS Pushbutton) SAGA1-L12 (11 Double-step Pushbuttons + 1 Single-step Pushbutton + EMS Pushbutton) SAGA1-L12-1 (12 Single-step Pushbuttons + EMS Pushbutton)
Structure:	Enhanced Glass Fiber
Emission Power:	< 10 mW
Power Supply:	2 AA Size Disposable Battery / Rechargeable (Ni-MH)
LED Power Indicator:	3 Stages Power Indicator
Dimension:	SAGA1-L10/L10-1 163 x 49 x 45 mm (L x W x H) SAGA1-L12/L12-1 274 x 77 x 42 mm (L x W x H)
Weight:	SAGA1-L10/L10-1 Approx. 210g (w/o Batteries) SAGA1-L12/L12-1 Approx. 400g (w/o Batteries)

Receiver Quick Specs

Dimension:	SAGA1-L10/L10-1 167 x 154 x 88 mm (L x W x H) SAGA1-L12/L12-1 253 x 267 x 150 mm (L x W x H)
Weight:	SAGA1-L10/L10-1 Approx. 1400g (w/o Cable) SAGA1-L12/L12-1 Approx. 3000g (w/o Cable)
Power Supply:	24/48/110/220/380 VAC (50 / 60Hz) ±20%, 12/24 VDC